

These hammock chairs are hand made and come in various colors and designs.

Some common places to hang a hammock chair include tree branches, ceiling beams and rafters. In order to safely get in and out of the hammock chair, allow approximately 2 feet of clearance between the bottom of the chair and the ground. To get into the hammock chair, stand with your back to it, and grasp the front edge of the chair with both hands. As you sit, pull the front edge of the chair toward your knees. Gently swinging in the hammock chair will add to your pleasure in use. However, it should never be spun, twisted or rotated. To do so will weaken the hammock and may lead to failure.

Care and Maintenance

To clean your hammock chair, hand wash (never machine wash) in a mild detergent. Do not use bleach or immerse the hardwood spacer bar in water. Rinse well and hang to dry in a sunny or well-ventilated place. A quick drying will keep the cotton in good shape.

To protect the hardwood spacer bar from the elements, give it a light sanding at least once a year, followed by a coat of tung oil or linseed oil. Wipe off any excess oil before leaving the spacer bar to dry.

Always bring the hammock indoors after use. It was never intended to be left outside. Make sure it is completely dry before storage. Do not store your hammock chair in a damp area.

Beware of pocket buttons, rivets, or any sharp object that can snag and break a string. If this happens, quickly tie the two broken ends together so the hammock doesn't grow a hole.

Caution: *Do not leave children unattended in the hammock chair.*



1090 Morrison Drive 814 Proctor Avenue
Ottawa ON K2H 1C2 Ogdensburg NY 13669-2205
Canada United States
1-800-267-8761 1-800-267-8735